



Using Hansen Solubility Parameters for Identifying Safer Solvent Alternatives

November 15, 2016

Gregory Morose, Sc.D.

Toxics Use Reduction Institute

Presentation Topics


- Overview of Hansen Solubility Parameter Theory
- Hansen Solubility Parameters in Practice Software
- Methodology for identifying safer solvents
- Examples: safer paint strippers and safer contact adhesives

Use of Toxic Solvents

Problem: Solvents with toxic properties are used for numerous applications: adhesives, spot removers, coatings, paint thinners, dry cleaning, nail polish removers, etc.

Solution: The Toxics Use Reduction Institute (TURI) in partnership with UMass Lowell faculty and students are utilizing the Hansen Solubility Parameters in Practice (HSPiP) Software to identify safer solvent and solvent blends to provide safer alternatives to the use of toxic solvents.

The TUR Planning Cycle




Solvent use identified, for example: toluene, xylene, methanol, acetone, hexane, methyl ethyl ketone (MEK), methylene chloride, etc.

Identify safer solvent options and screen out options that are not financially and technically feasible

Hansen Solubility Parameters - Theory

Creating a Solution

Solute + Solvent = Solution



- Solute is the substance being dissolved, solvent is the substance that dissolves it. Both substances must be similar to dissolve the solute.

Hansen Solubility Parameters

- Hansen Solubility Parameters (HSP) is based on three intermolecular forces, focusing on the specific requirements for solubility.
- Based on “like dissolves like”, the more similar the solvent and solute, the more likely the ability to dissolve the solute.

Inter-molecular forces

Dispersion force (also called London Force)

- The electron cloud surrounding an atom is, on average, evenly distributed around the atom.
- However at a given moment, the electron distribution may not be even.
- This causes a temporary, non-localized (disperse) polarization force.

Polar force (also called dipole-dipole force)

- Dipole moments are created when atoms of the same molecule have different electronegativities.
- This causes a permanent polarization, from a specific, fixed location.

Hydrogen bonding force


- Occurs in molecules containing highly electronegative elements (i.e. F, O, or N) directly bound to hydrogen.
- This force exists between hydrogen atoms and other atoms present in adjacent molecules.

Strength of forces (on average): hydrogen bonding > polar > dispersion

Hansen Solubility Parameters in 3D Space


The solvent and solute can be characterized in 3 dimensional space using the three Hansen Solubility Parameters.

δ_d – Dispersion force
 δ_p – Polar force
 δ_h – Hydrogen-bonding force



“Like dissolves like” – the smaller the HSP distance between the solvent and solute, the more likely the solute can be dissolved.

“Like dissolves like”




Green Sphere: 3D HSP space in which a solvent will dissolve the solute (i.e. polymer)

Blue Dots: solvents that will dissolve the solute (inside or on surface of the green sphere)

Red Cubes: solvents that will not dissolve the solute (outside of the green sphere)

Solute
HSP
sphere



The RED number is the Relative Energy Difference and is calculated as follows:

$$\text{RED} = \frac{\text{distance (d) of your solvent (or solvent blend) to target HSP}}{\text{radius (r) of the target HSP Sphere for the solute}}$$


A perfect solvent has a RED of 0.

A solvent just on the surface of the Sphere has a RED of 1.

If $\text{RED} > 1$ then incompatible, if $\text{RED} < 1$ then compatible.

Relative RED values are useful. If you have a solvent of RED 0.2 and another of 0.4 you know (a) that neither is perfect and (b) that the first one is better.


Applications with Multiple Solutes




Junction Value - the sweet spot which would define the solvent HSP values most likely to interact well with each of the solutes (i.e. polymers).

Solvent Blends - Example

Solvent	Volume %	D	P	H
Solvent A	50%	12	4	21
Solvent B	50%	18	11	3
Solvent Blend		15	7.5	12



Hansen Solubility Parameters in Practice (HSPiP) Software



10,000+ chemicals (solvents) in the HSPiP database with associated chemical properties: HSP, Density, Mvol, Bpt, Mpt, RER, vapor pressure, etc.

HSP14 4th Edition 4.1.07 Licensed to: TURI Group License

File Dist. Diff. Adh./Visc. Force Fit Teas HPLC IGC GC Temp. Evap. FindMols. Grid DPC PowerTools Help GRAS

Double-Click Radius ☐ ESC Alert
4.0 ☐ Limit ☐ MVC ☐ GA
Total Compounds = 79

Both only
☐ Hide unused ☐ SRC
☐ SSEL ☐ D/A

Solvent Optimizer

Solvent	δD	δP	δH	MVol	Other Names	RER	Weight	Vol%	Distance	AA
Water	15.5	16	42.3	18	-	80	100		36.38	7.485
Isocyanic Acid	15.8	10.5	13.6	37.7	-	647.2	100		7.63	7.6385
Urea For Ro Equal 19.4	20.9	18.7	26.4	48.8	-	0.4	100		23.73	7.8218
Thiocyanic Acid	16.8	8.9	10.9	51.7	-	59.5	100		4.14	7.0559
Glyoxylic	17.97	16.45	19.53	54.8	-	1.6	100		15.56	7.5464
Methyl Isocyanide	15.69	17.14	6.27	57.2	-	152	100		10.22	6.9322
1,2-Propadiene (Allene)	15.3	3	6.8	60.4	-	153...	100		5.49	6.67
Acetaldoxime	16.3	4	20.2	61.2	-	29.6	100		13.58	7.4559
Methoxy Methanol	16	9	18.5	62	-	38	100		11.70	7.4609
Oxalamide	19.87	26.59	23.52	63.4	-	0	100		25.97	8.5029
Methyl Nitrate	15.8	14	4.8	63.8	-	472...	100		7.48	7.08
Succinic Anhydride	18.6	17.5	16	64.5	-	0.007	100		13.91	7.344
Cis-1,2-Difluoroethene	14.45	4.67	3.74	64.8	-	297...	100		6.65	6.9576
Trans-1,2-Difluoroethene	14.45	4.67	3.74	64.8	-	297...	100		6.65	6.9576
Dicyandiamide	18.97	18.23	11	65.7	-	0.2	100		12.26	6.5858
Biacetylene	16.52	5.77	1.31	65.9	-	630...	100		6.07	6.9278
Cyclobutene	16.65	3.65	4.74	67.6	-	614...	100		4.40	6.9925
Pyrazole	20.2	10.4	12.4	68.1	-	5	100		8.87	7.3005
Oxazole	18.03	10.33	7.89	68.1	-	212.4	100		3.75	7.1216
Methyl Glyoxal	15.5	16.1	9.7	68.9	-	128.3	100		9.65	7.1408
Pyrole	19.2	11	10	69.5	-	25....	100		6.44	7.048
Dibromomethane (Meth...	19	6.4	7	69.8	-	145...	100		4.10	7.039
Spiropentane	17.82	3.43	3.54	70	-	284...	100		5.51	6.7808
Biuret	20	14.6	18.8	70.3	-	0.1	100		15.04	8.1825
Ethyleneurea	19.71	14.65	12.46	70.4	-	0.1	100		10.59	7.6367
Trifluoromethane	13.77	4.08	2.51	70.5	-	139	100		8.55	6.9287

Target ☐ Show Hi-Lo
δD δP δH δHD/A
17.0 7.3 7.1 0.0/0.0 D/A
-2.0 -2.0 2.0 RED fit
Calculated
Delta
Distance RED Wt. Err % Check
Best 1 or 2 + 1.0 Radius 7.0
nBuAc=100s 1000 RERc
Air m/s μm
0.5 100.0
Time 10 Min
Activity Coeff. ☒ Show previous
Show RED ☐ Plot Ra
Inc. Target % 10.0
Evaporation °C
Wet-bulb % RH Dew-Point BRP
50.0 13.8
Auto Water RER ☐ Plot Wet

Solubility Graph Ctrl-Click to disable a solvent ☐ Only use bad solvents beyond R Search_Text C:\User...\Potentially Safer Chemicals.sof

Screen out chemicals with undesirable properties for a particular application

- Sort by parameter of interest: For example, select the column "MVol" (Molecular Volume)

HSPiP 4th Edition 4.1.07 Licensed to: TURI Group License

File Dist. Diff. Adh./Visc. Force Fit Teas HPLC IGC GC Temp. Evap. FindMols Grid DPC PowerTools Help GRAS

No.	Solvent	δD	δP	δH	Score	RED	MVol
1	Acetic Acid	14.5	8	13.5	-	-	57.6
2	Aconitic Acid	17.4	8.8	16.6	-	-	124.8
3	Adipic Acid	17.1	10	16.3	-	-	133.9
4	L-Ascorbic Acid	18	11.7	25.5	-	-	124.8
5	Ascorbyl Palmitate (Palmitoyl L-Ascorbic)	17	9.1	11.1	-	-	382.8
6	Benzoic Acid	20	6.9	10.8	-	-	112.4
7	Biotin	18.2	15.9	15.2	-	-	193.2
8	Butylated Hydroxyanisole (Bha)						
9	Caffeine						
10	Caprylic Acid						
11	Carbon Dioxide						
12	Carboxymethyl Cellulose						
13	Carnauba Wax						
14	Carotene (Beta - Carotene)						
15	Cellulose Acetate						
17	Cholic Acid						
16	Citric Acid						
17	Clove Oil (As Eugenol)						
18	Coconut Oil (As Lauric Acid)						
19	Desoxycholic Acid						
21	Diacetyl						
23	Erythorbic Acid (d-Isoscorbic Acid)						
24	Ethyl Formate						
25	Formic Acid (Packaging)						
26	L-Glutamic Acid						
27	Glycerin And Glycerides						
28	Glycocholic Acid						
29	Glycyrrhiza						
30	Hydrogen Peroxide						
31	Inositol						
32	Invert Sugar						
33	Isopropyl Citrate (As Monoglyceride)						
35	Lactic Acid						

δP v δH

Solvent Optimizer


Solvent	δD	δP	δH	MVol	Other Names	RER	Weight	Vol%	Distance	AA	AB
Water	15.5	16	42.3	18	-	80	100		36.38	7.485	1376
Isocyanic Acid	15.8	10.5	13.6	37.7	-	647.2	100		7.63	7.6385	1383
Urea For Ro Equal 19.4	20.9	18.7	26.4	48.8	-	0.4	100		23.73	7.8218	1920
Thiocyanic Acid	16.8	8.9	10.9	51.7	-	59.5	100		4.14	7.0559	1415
Glyoxylic	17.97	16.45	19.53	54.8	-	1.6	100		15.56	7.5464	1678
Methyl Isocyanide	15.69	17.14	6.27	57.2	-	152	100		10.22	6.9322	958.7
1,2-Propadiene (Allene)	15.3	3	6.8	60.4	-	153...	100		5.49	6.67	764.2
Acetaldoxime	16.3	4	20.2	61.2	-	29.6	100		13.58	7.4559	1509
Methoxy Methanol	16	9	18.5	62	-	38	100		11.70	7.4609	1426
Oxalamide	19.87	26.59	23.52	63.4	-	0	100		25.97	8.5029	2571
Methyl Nitrate	15.8	14	4.8	63.8	-	472...	100		7.48	7.08	1164
Succinic Anhydride	18.6	17.5	16	64.5	-	0.007	100		13.91	7.344	1908
Cis-1,2-Difluoroethene	14.45	4.67	3.74	64.8	-	297...	100		6.65	6.9576	723
Trans-1,2-Difluoroethene	14.45	4.67	3.74	64.8	-	297...	100		6.65	6.9576	723
Dicyandiamide	18.97	18.23	11	65.7	-	0.2	100		12.26	6.5858	1789
Biacetylene	16.52	5.77	1.31	65.9	-	630...	100		6.07	6.9278	955.2
Cyclobutene	16.65	3.65	4.74	67.6	-	614...	100		4.40	6.9925	1038
Pyrazole	20.2	10.4	12.4	68.1	-	5	100		8.87	7.3005	1573
Oxazole	18.03	10.33	7.89	68.1	-	212.4	100		3.75	7.1216	1289
Methyl Glyoxal	15.5	16.1	9.7	68.9	-	128.3	100		9.65	7.1408	1376
Pyrole	19.2	11	10	69.5	-	25....	100		6.44	7.048	1353
Dibromomethane (Meth...	19	6.4	7	69.8	-	145...	100		4.10	7.039	1313

Solvent Optimizer Settings:

- Double-Click Radius: 4.0
- Limit: ☐ ESC Alert
- MVC: ☐ GA
- Total Compounds = 79
- Both only: ☐ Hide unused ☐ SRC ☐ SSEL ☐ D/A
- Search_Text:
- Master: ☒ 10K: ☐ MyDB: ☐
- Buttons: P, S, O, **Pw**, Tw, L
- Target: δD 17.0, δP 7.3, δH 7.1, $\delta H/\delta P$ 0.0/0.0, RED fit ☐ D/A ☐
- Calculated: Delta:
- Distance RED Wt. Err % Check: 0.0 MChk
- Best 1 or 2 + 1.0 Radius 7.0
- nBuAc=100s 1000 RERC
- Airm/s μm : 0.5 100.0
- Time 10 Min
- Activity Coeff. ☒ Show previous ☐ Show RED ☐ Plot Ra
- Inc. Target % 10.0
- Evaporation: C
- Wet-bulb % RH Dew-Point BRP: 50.0 13.8
- Auto Water RER ☐ Plot Wet ☐

Determine solvent blends using an HSP target value


- Check off the desired solvents
- Select the “Pw” (pairwise) button (or “Tw” button for triplet wise combinations)



Find solvents that will dissolve a certain polymer

- Open Polymer form (600+ polymers)
- HSP green sphere for selected polymer and selected solvents (blue dots) shown in 3D space, solvents sorted by RED value

Safer Solvents Identification and Evaluation



TURI Examples


Application	Toxic Solvent(s)	Solute
Paint stripping	Methylene chloride	Various paints/coatings
Contact adhesives	Hexane and toluene	Rubber and resin

Determine Requirements

Categories	Examples
Cost	\$ per pound, \$ per gallon, etc.
Performance (requires testing to evaluate)	Material compatibility, solutes to dissolve, time to dissolve, strength requirements, etc.
Physical properties (inherent to individual solvents)	Evaporation rate, color, specific gravity, odor, etc.
Regulatory/environmental	HAPs free, VOC content, etc.


Sources: literature search, industry partners, etc.

Prioritize Requirements



Search and Screen Alternatives

- Thousands of different solvents to consider
- Numerous solvent requirements to consider
- Binary, ternary, and quaternary blend possibilities
- Iterative process: initial screen, revised screen, etc.
- Use of software tools to assist: Hansen Solubility Parameters in Practice (HSPiP), MS Excel



Search and Screen Alternatives

Example:

Specific gravity requirement of 0.80 to 0.90

Initial screen:

Look for solvents with specific gravity of 0.80 to 0.90

Revised screen:

Look for solvents with specific gravity of 0.70 to 1.0.

For example: one solvent at 50% with specific gravity of 0.75 and another solvent at 50% with specific gravity of 0.95

Subsequent revised screen:

Look for solvents with specific gravity of 0.5 to 1.4.

For example: one solvent with specific gravity of 0.80 at 95%, and one solvent with a specific gravity of 1.4 at 5%.

Determine Solvency Target

Target HSP Parameters – Paint Stripper Example

1) Based on target chemical D, P, H value

methylene chloride: 17, 7.3, 7.1

However, the chemical is used as part of a solvent blend.

2) Based on target product (solvent blend)

Paint Stripper product formulation X (low methylene chloride content, methanol, toluene, and acetone)

Paint Stripper product formulation Y (high methylene chloride content methanol, and toluene)

However, the products may not be optimized for the target application.

Target HSP Parameters – Paint Stripper Example

Create an model in MS Excel based on polymer HSP values included in the HSPiP database. The model contains HSP values for 59 different types of paints/coatings from various manufacturers (including alkyd, amino resin, cellulose acetate, epoxy, polyacrylate, polyamide, polyester, polyurethane, polyvinylbutyral, chlorinated polypropylene, polyvinylacetate, shellac, silicone, and methacrylate).

Polymer/Product Name	D	P	H	Radius	Polymer Type
Desmophen 1100	16	13.1	9.2	11.4	Polyester
Epikote 828	23.1	14.6	5	20.5	Epoxy
Desmolac 4200	18.7	9.6	9.9	8.2	Polyurethane

Target HSP Parameters – Paint Stripper Example

For each solvent or solvent blend that you enter into the Excel model, it will provide the following output:

% Effectiveness: the percentage of the 59 coatings that the solvent blend will dissolve.

Average distance: the average distance from the HSP sphere center for each of the 59 coatings.

Create HSP Spheres for Contact Adhesives

No existing polymer HSP data for specific rubber and resins used in target contact adhesives.

Contact adhesive 1: Rubber A, Resin B

Contact adhesive 2: Rubber C, Resin D



Add polymer samples and solvent into test tubes



Create HSP Spheres for Contact Adhesives



Repeat for 20 – 30 different solvents

After 24 hour dwell time, record results.

Score = 1 (polymer dissolves, inside sphere)

Score = 0 (polymer does not dissolve, outside sphere)

Enter values into HSPiP software to create the 3D HSP sphere




HSP Sphere for Rubber X

HSPiP 4th Edition 4.1.07 Licensed to: TURI Group License



File Dist. Diff. Adh./Visc. Force Fit Teas HPLC IGC GC Temp. Evap. FindMols Grid DPC PowerTools Help

Test Solvents ITW Sphere NEO with scores oct 27 2015 final

No.	Solvent	δD	δP	δH	Score	RED	MVol
7	Acetone	15.5	10.4	7	0	1.672	73.8
10	Acetonitrile	15.3	18	6.1	0	2.767	52.9
102	n-Butyl Acetate	15.8	3.7	6.3	0	1.036	132.6
156	Chloroform	17.8	3.1	5.7	1	0.283	80.5
9999	DBE	16.2	4.7	8.4	0	1.158	135.3
267	Diethylene Glycol Monobutyl Ether	16	7	10.6	0	1.761	170.4
303	Dimethyl Sulfoxide	18.4	16.4	10.2	0	2.619	71.3
306	1,4-Dioxane	17.5	1.8	9	1	0.978	85.7
16615	Dipropylene Glycol Monomethyl Ether	16.1	6.7	10.4	0	1.651	153.9
325	Ethanol 99.9%	15.8	8.8	19.4	0	2.991	58.6
326	Ethanolamine	17	15.5	21	0	3.738	60.3
328	Ethyl Acetate	15.8	5.3	7.2	0	1.106	98.6
417	Hexane	14.9	0	0	0	1.826	131.4
481	MEK	16	9	5.1	0	1.327	90.2
456	Methanol	14.7	12.3	22.3	0	3.588	40.6
464	Methyl Acetate	15.5	7.2	7.6	0	1.340	79.8
521	N-Methyl Pyrrolidone	18	12.3	7.2	0	1.778	96.6
524	Methylene Dichloride	17	7.3	7.1	1	0.910	64.4
9999	N Butyl Acetate 50%, Tce 50%	17	4.7	3.1	1	0.000	0
592	PMA	15.6	5.6	9.8	0	1.580	137.1
570	2-Propanol	15.8	6.1	16.4	0	2.476	76.9
584	Propylene Carbonate	20	18	4.1	0	2.870	85.2
615	TCE	18.3	5.7	0	1	0.996	102.8
617	Tetrahydrofuran	16.8	5.7	8	1	0.918	81.9
637	Toluene	18	1.4	2	1	0.704	106.6
9999	Toluene 50%, Methylene Dichloride 50%	17.5	4.3	4.6	1	0.267	100
1059	Undecane	16	0	0	0	1.645	212.2




Performance Test: Paint Stripper



- Glue a ring gasket on the test area of the test vehicle
- Use a clean pipette to add approx. 1.5 ml of solvent blend inside the ring gasket
- Cover the gasket with lab watch glass
- Start timer to initiate dwell time
- Record initial cracking time
- After dwell time: remove watch glass
- Lightly scrape off coating residue with plastic scraper & record substrate exposure

Performance Test: Contact Adhesive



Optimize Formulations

- Narrow down to a limited number of preferred target solvents
- Determine key criteria
- Develop MATLAB scripts with constraints
- Utilize MATLAB to optimize the formulations based upon key criteria

Contact adhesive MATLAB Script includes the following:

- Cost (\$/L)
- VOC level (g/L)
- Density
- HSP parameters (D, P, H)
- HSP distance from the polymer
- HSP distance from the resin
- Whether it falls in the solubility sphere
- Include 7 target solvents

Finalize Formulation

Select the final formulation that meets all requirements, passed all performance tests, and has been optimized.

Contact

Questions about:

- Hansen Solubility Parameters
- Hansen Solubility Parameters in Practice (HSPiP) software
- Identifying and evaluating safer solvents

Greg Morose, TURI

Gregory_Morose@uml.edu

978-934-2954